

Information about joint sealants can be found in details OR-E-105 and OR-E-106.

Attention!

Joints always at same level for cover flashings as for horizontal panel joint!

Never install two flashings together with screws in length direction!

Use butyl tape over the support flashing joints!

Always use a tape roller on sealant tapes to ensure maximum sealant effectivity!

