



Information about joint sealants can be found in details OR-E-105 and OR-E-106.

Attention!



Joints always at same level for cover flashings as for horizontal panel joint!
Never install two flashings together with screws in length direction!

Always use a tape roller on sealant tapes to ensure maximum sealant effectivity!


A, At panel ends

AFPIU, Steel profile $t=1.25$ mm

Fill the gaps with compound where there is TT-41 at panel ends

(TT-41) Sealant tape, butyl

Small pieces of butyl tape over the panel end joint and 100mm up on the panel surface when wind load over 0.7 kN/m^2
Type 1

C, Behind column

Type 2
