



Always use a tape roller on sealant tapes to ensure maximum sealant effectivity!



Attention!

Joints always at same level for cover flashings as for horizontal panel joint!
Never install two flashings together with screws in length direction!



* Maximum allowed load/stripe: 0.5 kN

[X] Supplier Paroc Panel System